

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Original Formula & Botanical Polymerized Tung Oil

Use our Original Formula Polymerized Tung Oil Sealer or Botanical Polymerized Tung Oil Sealer 1–2 coats prior to grouting as a grout release. Once the grout is dry and the stone is clean, reapply the Sealer or Low Lustre to restore the sheen and seal the grout.

Grout Release Instructions

step 1:

- Apply Sealer
- Let cure 24 hours

step 2:

- Apply Sealer
- Let cure 24 hours

step 2:

- Grout stone

Follow grout manufactures instructions for cleaning and curing time.

Then continue on to perfered top coat application to seal the grout and stone.

Top Coat Instructions

Low Sheen

step 1:

- Apply Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 2:

- Apply Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 3:

- Apply Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Porous Stone

Stone Preparation

All stone surfaces should be free of lint, dirt, grease, wax, oil. Clean the stone surface with 1 cup ammonia and 1 gallon water. Dry thoroughly.

Applicator Options

Brush: Natural white china bristle brush (thin coats only)

Cure Test

Push finger tips across the stone. If they glide easily over the surface, you are ready to apply your next coat

Top Coat Instructions

Medium Sheen

step 1:

- Apply Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 2:

- Apply Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 3:

- Apply Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours