

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Original Formula & Botanical Polymerized Tung Oil

Use our Original Formula Polymerized Tung Oil Sealer or Botanical Polymerized Tung Oil Sealer 1–2 coats prior to grouting as a grout release. Once the grout is dry and the stone is clean, reapply the Sealer or Low Lustre to restore the sheen and seal the grout.

### Grout Release Instructions

**step 1:**

- Apply Sealer
- Let cure 24 hours

**step 2:**

- Apply Sealer
- Let cure 24 hours

**step 2:**

- Grout stone

Follow grout manufactures instructions for cleaning and curing time.

Then continue on to perfered top coat application to seal the grout and stone.

### Top Coat Instructions

#### Low Sheen

**step 1:**

- Apply Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

**step 2:**

- Apply Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

**step 3:**

- Apply Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

## Porous Stone

### Stone Preparation

All stone surfaces should be free of lint, dirt, grease, wax, oil. Clean the stone surface with 1 cup ammonia and 1 gallon water. Dry thoroughly.

### Applicator Options

**Brush:** Natural white china bristle brush (thin coats only)

### Cure Test

Push finger tips across the stone. If they glide easily over the surface, you are ready to apply your next coat

### Top Coat Instructions

#### Medium Sheen

**step 1:**

- Apply Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

**step 2:**

- Apply Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

**step 3:**

- Apply Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours