

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Exterior Polymerized Tung Oil Sealer or Medium Lustre

Smooth Surfaces

We recommend using Exterior Polymerized Tung Oil Sealer. The lower Tung Oil content will penetrate deeper into the smooth surface providing better adhesion and sheen control.

Rough Surfaces

We recommend using Exterior Polymerized Tung Oil Medium Lustre. Rough surfaces will absorb more oil. The higher percentage of Tung Oil in Exterior Medium Lustre will provide better protection with lower square foot cost.

Smooth Surface Low Sheen Instructions

step 1:

- Apply Exterior Sealer
- Don't wipe
- Let cure 6-8 hours

step 2:

- Sand 400 grit
- Vacuum & tack surface
(use Mineral Sprits on a rag to clean surface)

step 3:

- Apply Exterior Sealer
- Don't wipe
- Let cure 24 hours

step 4:

- Sand 600 grit
- Vacuum & tack surface

step 5:

- Apply Exterior Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Smooth Surface Medium Sheen Instructions

step 1:

- Apply Exterior Sealer
- Don't wipe
- Let cure 6-8 hours

step 2:

- Sand 400 grit
- Vacuum & tack surface
(use Mineral Sprits on a rag to clean surface)

step 3:

- Apply Exterior Sealer
- Don't wipe
- Let cure 24 hours

step 4:

- Sand 600 grit
- Vacuum & tack surface

step 5:

- Apply Exterior Sealer
- Don't wipe
- Let cure 24 hours

step 6:

- Sand 600 grit
- Vacuum & tack surface

step 7:

- Apply Exterior Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Exterior Siding

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 120 grit paper (smooth surface only)**. Avoid using higher grits as they close down the wood pores interfering with maximum penetration.

Applicator Options

Brush: Natural white china bristle brush (thin coats only)

Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Rough Surface Instructions

step 1:

- Apply Exterior Medium Lustre
- Don't wipe
- Let cure 6-8 hours

step 2:

- Apply Exterior Medium Lustre
- Don't wipe
- Let cure 24 hours

step 3:

- Apply Exterior Medium Lustre
- Don't wipe
- Let cure 24 hours

Repeat step 3 for higher sheen.