

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Murdoch's Hard Sealer or Uralkyd 500 Floor Finish

Some drums require a highly polished appearance that needs to be extremely hard. The Murdoch's line offers the best approach for achieving this goal. Murdoch's Hard Sealer applied as the initial coats enhance the grain definition that is often characteristic of the wood species chosen for drums. The final appearance is produced by the choice of topcoat. Murdoch's Uralkyd 500 Gloss or Satin provide maximum protection and a mirror-like finish with a brush-on application.

Satin Sheen Instructions

step 1:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 2-3 hours

step 2:

- Sand 400 grit
- Vacuum & tack surface
(use Mineral Sprits on a rag to clean surface)

step 3:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 4-6 hours

step 4:

- Sand 600 grit
- Vacuum & tack surface

step 5:

- Apply Murdoch's Uralkyd Satin
- Let cure 24 hours

step 6:

- Sand 600 grit
- Vacuum & tack surface

step 7:

- Apply Murdoch's Uralkyd Satin
- Let cure 24 hours

Drums Polished Look

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration.

Applicator Options

Brush: Natural white china bristle brush (thin coats only)

Cure Test

Lightly sand several inconspicuous areas. A fine, white powder indicates that you can safely apply another coat.

Gloss Sheen Instructions

step 1:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 2-3 hours

step 2:

- Sand 400 grit
- Vacuum & tack surface
(use Mineral Sprits on a rag to clean surface)

step 3:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 4-6 hours

step 4:

- Sand 600 grit
- Vacuum & tack surface

step 5:

- Apply Murdoch's Uralkyd Gloss
- Let cure 24 hours

step 6:

- Sand 600 grit
- Vacuum & tack surface

step 7:

- Apply Murdoch's Uralkyd Gloss
- Let cure 24 hours