

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Murdoch's Hard Sealer

The combination of the Botanical Polymerized Tung Oil and urethane/alkyd resin in this products helps build a uniform film finish with a brushed technique. The number of coats applied and the process determines the sheen levels. For plywood doors and wall paneling, the brushed technique and this product create a uniform appearance.

### Low Sheen Instructions

#### step 1:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 2-3 hours

#### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

#### step 3:

- Apply Murdoch's Hard Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 4-6 hours

#### step 4:

- Sand if rough (600 grit)

#### step 5:

- Apply Murdoch's Hard Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

### Medium Sheen Instructions

#### step 1:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 2-3 hours

#### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

#### step 3:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 4-6 hours

#### step 4:

- Sand 600 grit
- Vacuum & tack surface

#### step 5:

- Apply Murdoch's Hard Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### step 6:

- Sand if rough (600 grit)

#### step 7:

- Apply Murdoch's Hard Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

## Interior Doors, Walls & Trim

### Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration.

### Applicator Options

**Rag:** Scott® blue paper shop towels

**Brush:** Natural white china bristle brush (thin coats only)

### Cure Test

Lightly sand several inconspicuous areas. A fine, white powder indicates that you can safely apply another coat.

### High Sheen Instructions

#### step 1:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 2-3 hours

#### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

#### step 3:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 4-6 hours

#### step 4:

- Sand 600 grit
- Vacuum & tack surface

#### step 5:

- Apply Murdoch's Hard sealer
- Don't wipe
- Let cure 24 hours

#### step 6:

- Sand 600 grit
- Vacuum & tack surface

#### step 7:

- Apply Murdoch's Hard Sealer
- Don't wipe
- Let cure 24 hours