

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Old World Concentrated Stain

To create a totally saturated color in the wood omit using a clear Sealer coat and don't dilute the stain. It will require multiple applications to create a totally saturated color. The sheen increases with each coat of stain.

Stain Instructions

step 1:

- Apply Stain
- Don't wipe
- Let cure 24 hours

step 2:

- Sand lightly 600 grit
- Vacuum & tack surface
(use Mineral Sprits on a rag to clean surface)

step 3:

- Apply Stain
- Don't wipe
- Let cure 24 hours

Repeat steps 1-2 until desired depth of saturation is achieved.

Total Saturation Staining

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration.

Applicator Options

Rag: Scott® blue paper shop towels

Brush: Natural white china bristle brush (thin coats only)

Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Top Coat Options & Instructions

Original Formula or Botanical Polymerized Tung Oil Low, Medium or High Lustre

step 8:

- Apply Original or Botanical
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 9:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 10:

- Apply Original or Botanical
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Wiping Varnish

Low, Medium or High Lustre

step 8:

- Apply Wiping Varnish
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 9:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 10:

- Apply Wiping Varnish
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Murdoch's Uralkyd 500 Floor Finish Matte, Satin or Gloss

step 8:

- Apply Murdoch's Uralkyd
- Let cure 24 hours

step 9:

- Sand 600 grit
- Vacuum & tack surface

step 10:

- Apply Murdoch's Uralkyd
- Let cure 24 hours

Murdoch's Table Top Satin or Gloss

step 8:

- Apply Murdoch's Table Top
- Let cure 24 hours

step 9:

- Sand 600 grit
- Vacuum & tack surface

step 10:

- Apply Murdoch's Table Top
- Let cure 24 hours