

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



We always recommend brushing out the stain as you have better contact with the wood. If you want to speed the process along, apply the stain with a lamb's wool applicator – thinly and then back brush it in. Brushing gives you an even, uniform layer. If you get too much on and you have bubbles and brush strokes, brush excess onto next section of boards.

## Penetrating Stain Instructions

### step 1:

- Apply clear coat Sealer
- Don't wipe
- Let cure 6-8 hours

### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

### step 3:

- Mix Sealer & Stain  
(use determined Sealer : Stain ratio)

### step 4:

- Apply Sealer & Stain mixture
- Don't wipe
- Let cure 24 hours

### step 5:

- Sand lightly 600 grit
- Vacuum & tack surface

### step 6:

- Apply Sealer & Stain mixture  
(Adjust stain ratio if needed)
- Don't wipe
- Let cure 24 hours

### step 7:

- Sand lightly 600 grit
- Vacuum & tack surface

## Top Coat Instructions Matte, Satin or Gloss

### step 8:

- Apply Murdoch's Uralkyd
- Let cure 24 hours

### step 9:

- Sand 600 grit or **used** screen 120/150 grit or **used** synthetic 3M™ maroon BCP
- Vacuum & tack surface

### step 10:

- Apply Murdoch's Uralkyd
- Let cure 24 hours

## Staining Your Floor

### Applicator Options

**Brush:** Natural white china bristle brush (thin coats only)

**Lamb's Wool applicator**

**Rag:** Scott® blue paper shop towels

### Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

## Glazing Stain Instructions

### step 1:

- Apply clear coat Hard Sealer
- Don't wipe
- Let cure 6-8 hours

### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

### step 3:

- Mix Hard Sealer & Stain  
(use determined Sealer : Stain ratio)

### step 4:

- Apply Hard Sealer & Stain mixture
- Don't wipe
- Let cure 24 hours

### step 5:

- Sand lightly 600 grit
- Vacuum & tack surface

### step 6:

- Apply Hard Sealer & Stain mixture  
(Adjust stain ratio if needed)
- Don't wipe
- Let cure 24 hours

### step 7:

- Sand lightly 600 grit
- Vacuum & tack surface

## Rustic Stain Instructions

### step 1:

- Apply clear coat Sealer
- Don't wipe
- Let cure 6-8 hours

### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

### step 3:

- Mix Sealer & Stain  
(use determined Sealer : Stain ratio)

### step 4:

- Apply Sealer & Stain mixture
- Wipe to desired color depth
- Let cure 24 hours

### step 5:

- Sand lightly 600 grit
- Vacuum & tack surface

### step 6:

- Apply Sealer & Stain mixture  
(Adjust stain ratio if needed)
- Wipe to desired color depth
- Let cure 24 hours

### step 7:

- Sand lightly 600 grit
- Vacuum & tack surface

### Dilution Schedule for Stain

**Tint** 8 parts Sealer : 1 parts stain  
**Light** 6 parts Sealer : 1 parts stain  
**Medium** 4 parts Sealer : 1 parts stain  
**Dark** 2 parts Sealer : 1 parts stain