

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Kitchen & Bath Cabinets

### Wiping Varnish

The Wiping Varnish has an equal amount of Polymerized Tung Oil and urethane, combined with a mineral spirits solvent. The higher percentage of Tung Oil in this formulation creates a softer, supple feel to the surface, while still offering great moisture protection.

### Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration.

### Applicator Options

**Rag:** Scott® blue paper shop towels

**Brush:** Natural white china bristle brush (thin coats only)

**Spray:** HVLP compatible (no dilution necessary)

### Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

### Low Sheen Instructions

#### step 1:

- Apply Wiping Varnish Sealer
- Wait 30 min.
- Wipe unabsorbed finish
- Let cure 6-8 hours

#### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

#### step 3:

- Apply Wiping Varnish Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### step 4:

- Sand 600 grit
- Vacuum & tack surface

#### step 5:

- Apply Wiping Varnish Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### step 6:

- Sand if rough (600 grit)

#### step 7:

- Apply Wiping Varnish Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

### Medium Sheen Instructions

#### step 1:

- Apply Wiping Varnish Sealer
- Wait 30 min.
- Wipe unabsorbed finish
- Let cure 6-8 hours

#### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

#### step 3:

- Apply Wiping Varnish Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### step 4:

- Sand 600 grit
- Vacuum & tack surface

#### step 5:

- Apply Wiping Varnish Medium Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### step 6:

- Sand if rough (600 grit)

#### step 7:

- Apply Wiping Varnish Medium Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

### High Sheen Instructions

#### step 1:

- Apply Wiping Varnish Sealer
- Wait 30 min.
- Wipe unabsorbed finish
- Let cure 6-8 hours

#### step 2:

- Sand 400 grit
- Vacuum & tack surface  
(use Mineral Sprits on a rag to clean surface)

#### step 3:

- Apply Wiping Varnish Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### step 4:

- Sand 600 grit
- Vacuum & tack surface

#### step 5:

- Apply Wiping Varnish High Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### step 6:

- Sand if rough (600 grit)

#### step 7:

- Apply Wiping Varnish High Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours