

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Food Grade Counter & Bar Top

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration in the initial coat.

Applicator Options

Rag: Scott® blue paper shop towels

Brush: Natural white china bristle brush (thin coats only)

Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Botanical Polymerized Tung Oil

If the counter is made from Hard or Rock Maple or if you prefer some level of sheen, we recommend that you use the Botanical Polymerized Tung Oil in the desired Lustre.

Low Sheen Instructions

Low Lustre ONLY

step 1:

- Apply *Low Lustre*
- Don't Wipe
- Let cure 24 hours

step 2:

- Sand 400 grit
- Vacuum & tack surface
(use Mineral Sprits on a rag to clean surface)

step 3:

- Apply *Low Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 4:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 5:

- Apply *Low Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 6:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 7:

- Apply *Low Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Medium Sheen Instructions

Medium Lustre ONLY

step 1:

- Apply *Medium Lustre*
- Don't Wipe
- Let cure 24 hours

step 2:

- Sand 400 grit
- Vacuum & tack surface
(use Mineral Sprits on a rag to clean surface)

step 3:

- Apply *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 4:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 5:

- Apply *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 6:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 7:

- Apply *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

High Sheen Instructions

High Lustre ONLY

step 1:

- Apply *High Lustre*
- Don't Wipe
- Let cure 24 hours

step 2:

- Sand 400 grit
- Vacuum & tack surface
(use Mineral Sprits on a rag to clean surface)

step 3:

- Apply *High Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 4:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 5:

- Apply *High Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 6:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 7:

- Apply *High Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)