

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Botanical Polymerized Tung Oil

We recommend the Botanical Polymerized Tung Oil to create a hand-rubbed natural look on Drums. These finishes keep the wood protected and responsive with minimal surface build. Different levels of sheens are possible.

### Low Sheen Instructions

#### **Low Lustre ONLY**

##### **step 1:**

- Apply *Low Lustre*
- Don't Wipe
- Let cure 24 hours

##### **step 2:**

- Sand (400 grit)
- Vacuum & tack surface

(use Mineral Sprits on a rag to clean surface)

##### **step 3:**

- Apply *Low Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### **step 4:**

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

##### **step 5:**

- Apply *Low Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### **step 6:**

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

##### **step 7:**

- Apply *Low Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

### Medium Sheen Instructions

#### **Medium Lustre ONLY**

##### **step 1:**

- Apply *Medium Lustre*
- Don't Wipe
- Let cure 24 hours

##### **step 2:**

- Sand (400 grit)
- Vacuum & tack surface

(use Mineral Sprits on a rag to clean surface)

##### **step 3:**

- Apply *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### **step 4:**

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

##### **step 5:**

- Apply *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### **step 6:**

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

##### **step 7:**

- Apply *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

## Drums Natural Look

### Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration in the initial coat.

### Applicator Options

**Rag:** Scott® blue paper shop towels

**Brush:** Natural white china bristle brush (thin coats only)

### Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

### High Sheen Instructions

#### **High Lustre ONLY**

##### **step 1:**

- Apply *High Lustre*
- Don't Wipe
- Let cure 24 hours

##### **step 2:**

- Sand (400 grit)
- Vacuum & tack surface

(use Mineral Sprits on a rag to clean surface)

##### **step 3:**

- Apply *High Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### **step 4:**

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

##### **step 5:**

- Apply *High Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### **step 6:**

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

##### **step 7:**

- Apply *High Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

entle use after 24 hours. Light use after 7 days. LL cure through after 30 days (+/- based on local humidity/elevation/temperature)