

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Botanical Polymerized Tung Oil

Use our Botanical Polymerized Tung Oil Sealer for 1–2 coats prior to grouting as a grout release. Once the grout is dry and the stone is clean, reapply the Sealer or Low Lustre Tung Oil to restore the sheen and seal the grout.

### Grout Release Instructions

#### Sealer *ONLY*

##### step 1:

- Apply Sealer
- Let cure 24 hours

##### step 2:

- Apply Sealer
- Let cure 24 hours

##### step 3:

- Grout stone

#### *Follow grout manufactures*

*instructions for cleaning and curing time.*

*Then continue on to preferred top coat application to seal the grout and stone.*

### Top Coat Instructions

#### Low Sheen

#### Sealer *ONLY*

##### step 1:

- Apply Sealer
- Don't Wipe
- Let cure 24 hours

##### step 2:

- Apply Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### step 3:

- Apply Sealer
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

### Top Coat Instructions

#### Medium-High Sheen

#### *Low Lustre ONLY*

##### step 1:

- Apply *Low Lustre*
- Don't Wipe
- Let cure 24 hours

##### step 2:

- Apply *Low Lustre*
- Don't Wipe
- Let cure 24 hours

##### step 3:

- Apply *Low Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

*For Higher Sheen levels, repeat step 3*

## Porous Stone

### Stone Preparation

All stone surfaces should be free of lint, dirt, grease, wax, oil. Clean the stone surface with 1 cup ammonia and 1 gallon water. Dry thoroughly.

### Applicator Options

**Brush:** Natural white china bristle brush (thin coats only)

### Coat Cure Test

Push finger tips across the stone. If they glide easily over the surface, you are ready to apply your next coat

*Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)*