

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Total Saturation Stain Interior/Original Top Coat

Interior Polymerized Tung Oil & Old World Concentrated Stain

To create a totally saturated color in the wood omit using a clear Sealer coat and don't dilute the stain. It will require multiple applications to create a totally saturated color. The sheen increases with each coat of stain. The finishing process is completed with the application of the Interior/Original Formula in any lustre for producing the desired level of sheen.

Total Saturation Instructions

Use choice Interior/Original Lustre

step 1:

- Apply *Old World Stain*
- Do not wipe.
- Let cure 24 hours

step 2:

- Sand (600 grit or fine steel wool)
- Vacuum & tack surface

(use Mineral Spirits on a rag to clean surface)

step 3:

- Apply *Old World Stain*
- Do not Wipe
- Let cure 24 hours

step 4:

- Sand (600 grit or fine steel wool)
- Vacuum & tack surface

Repeat steps 3-4 until desired depth of saturation is achieved.

step 5:

- Apply *Interior/Original Chosen Lustre*
- Wait 20-25 min
- Wipe unabsorbed finish
- Let cure 24 hours

step 6:

- Sand lightly (600 grit or fine steel wool)
- Vacuum & tack surface

step 7:

- Apply *Interior/Original Chosen Lustre*
- Wait 20-25 min
- Wipe unabsorbed finish
- Let cure 24 hours

Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration in the initial coat.

Applicator Options

Rag: Scott® blue paper shop towels

Brush: Natural white china bristle brush (thin coats only)

Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Total Saturation Stain Botanical Top Coat

Botanical Polymerized Tung Oil & Old World Concentrated Stain

To create a totally saturated color in the wood omit using a clear Sealer coat and don't dilute the stain. It will require multiple applications to create a totally saturated color. The sheen increases with each coat of stain. The finishing process is completed with the application of the Botanical Polymerized Tung Oil in any lustre for producing the desired level of sheen.

Total Saturation Instructions

Use choice Botanical Lustre

step 1:

- Apply Stain.
- Do Not Wipe.
- Let cure 24 hours.

step 2:

- Sand lightly (600 grit)
- Vacuum & tack surface

(use Mineral Spirits on a rag to clean surface)

step 3:

- Apply Stain
- Don't wipe
- Let cure 24 hours

step 4:

- Sand lightly (600 grit or #0000 steel wool)
- Vacuum & tack surface

Repeat steps 3-4 until desired depth of saturation is achieved.

step 5:

- Apply *Botanical Choice Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 6:

- Sand lightly (600 grit or #0000 steel wool)
- Vacuum & tack surface

step 7:

- Apply Botanical Low Lustre
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration in the initial coat.

Applicator Options

Rag: Scott® blue paper shop towels

Brush: Natural white china bristle brush (thin coats only)

Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Total Saturation Stain Wiping Varnish Top Coat

Interior Polymerized Tung Oil & Old World Concentrated Stain

To create a totally saturated color in the wood omit using a clear Sealer coat and don't dilute the stain. It will require multiple applications to create a totally saturated color. The sheen increases with each coat of stain. The finishing process is completed with the application of the Wiping Varnish in any lustre for producing the desired level of sheen.

Total Saturation Instructions

Use Wiping Varnish Lustre of Choice

step 1:

- Apply *Old World Stain*
- Do not wipe.
- Let cure 24 hours

step 2:

- Sand (600 grit or fine steel wool)
- Vacuum & tack surface
(use Mineral Spirits on a rag to clean surface)

step 3:

- Apply *Old World Stain*
- Do not Wipe
- Let cure 24 hours

step 4:

- Sand (600 grit or fine steel wool)
- Vacuum & tack surface

Repeat steps 3-4 until desired depth of saturation is achieved.

step 5:

- Apply *Wiping Varnish Chosen Lustre*
- Wait 20-25 min
- Wipe unabsorbed finish
- Let cure 24 hours

step 6:

- Sand lightly (600 grit or fine steel wool)
- Vacuum & tack surface

step 7:

- Apply *Wiping Varnish Chosen Lustre*
- Wait 20-25 min
- Wipe unabsorbed finish
- Let cure 24 hours

Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration in the initial coat.

Applicator Options

Rag: Scott® blue paper shop towels

Brush: Natural white china bristle brush (thin coats only)

Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Murdoch's Finishes & Old World Concentrated Stain

To create a totally saturated color in the wood omit using a clear Sealer coat and don't dilute the stain. It will require multiple applications to create a totally saturated color.

The sheen increases with each coat of stain. The finishing process is completed by using either our Murdoch's Table Top or Uralkyd 500 Floor Finish for producing the desired level of sheen and protection.

Stain Instructions

step 1:

- Apply *Old World Stain*
- Do not wipe.
- Let cure 24 hours

step 2:

- Sand (600 grit or fine steel wool)
 - Vacuum & tack surface
- (use Mineral Spirits on a rag to clean surface)

step 3:

- Apply *Old World Stain*
- Do not wipe.
- Let cure 24 hours

step 4:

- Sand (600 grit or fine steel wool)
- Vacuum & tack surface

Repeat steps 3-4 until desired depth of saturation is achieved.

Table Top

*For moderate to heavy use
Either Satin or Gloss*

step 5:

- Apply *Table Top Choice Lustre*
- Do Not Wipe
- Let cure 24 hours

step 6:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 7:

- Apply *Table Top Choice Lustre*
- Do Not Wipe
- Let cure 24 hours

Total Saturation Stain Murdoch's Top Coat

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration in the initial coat.

Applicator Options

Rag: Scott® blue paper shop towels

Brush: Natural white china bristle brush (thin coats only)

Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Top Coat Finishing Instructions

Uralkyd 500 Floor Finish

*For heavy to commercial use
Either Matte, Satin, or Gloss*

step 5:

- Apply *Uralkyd 500 Choice Lustre*
- Do Not Wipe
- Let cure 24 hours

step 6:

- Sand if rough (600 grit or fine steel wool)
- Vacuum & tack surface

step 7:

- Apply *Uralkyd 500 Choice Lustre*
- Do Not Wipe
- Let cure 24 hours

Gentle use after 24 hours. Resin fully cures through 7-14 days & full tung oil cure through after 30 days
(+/- based on local humidity/elevation/temperature)