

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Interior/Original Formula Polymerized Tung Oil

Use our Original Formula Polymerized Tung Oil Sealer for 1–2 coats prior to grouting as a grout release. Once the grout is dry and the stone is clean, reapply the Sealer or Low Lustre to restore the sheen and seal the grout.

Grout Release Instructions

step 1:

- Apply *Sealer*
- Let cure 24 hours

step 2:

- Apply *Sealer*
- Let cure 24 hours

step 3:

- Grout stone

Follow grout manufactures instructions for cleaning and curing time.

Then continue on to perfered top coat application to seal the grout and stone.

Top Coat Instructions Low Sheen

SEALER ONLY

step 1:

- Apply *Sealer*
- Don't Wipe
- Let cure 24 hours

step 2:

- Apply *Sealer*
- Wait 25-30 min.
- Wipe unabsorbed finish
- Let cure 24 hours

step 3:

- Apply *Sealer*
- Wait 25-30 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Porous Stone

Stone Preparation

All stone surfaces should be free of lint, dirt, grease, wax, oil. Clean the stone surface with 1 cup ammonia and 1 gallon water. Dry thoroughly.

Applicator Options

Brush: Natural white china bristle brush (thin coats only)

Coat Cure Test

Push finger tips across the stone. If they glide easily over the surface, you are ready to apply your next coat

Top Coat Instructions Medium Sheen

Low Lustre ONLY

step 1:

- Apply *Low Lustre*
- Don't Wipe
- Let cure 24 hours

step 2:

- Apply *Low Lustre*
- Don't Wipe
- Let cure 24 hours

step 3:

- Apply *Low Lustre*
- Wait 25-30 min.
- Wipe unabsorbed finish
- Let cure 24 hours

For Higher Sheen levels, repeat step 3

Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)