

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Exterior Polymerized Tung Oil Sealer & Medium Lustre

Windows

We recommend our Exterior Sealer which penetrates deeply, followed by the higher Tung Oil in the Exterior Medium Lustre to best protect the wood.

Doors

There is often a canopy over a door that will protect the majority of the door leaving the bottom more exposed. Exterior Sealer penetrates deeply followed by topcoats of Exterior Medium Lustre to protect the door. An oil finish will allow you to spot repair areas of the door that need refurbishing.

Low Sheen Instructions

step 1:

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 12-24 hours

step 2:

- Sand (400 grit)
- Vacuum & tack surface
(use Mineral Spirits on a rag to clean surface)

step 3:

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 24 hours

step 4:

- Sand (600 grit)
- Vacuum & tack surface

step 5:

- Apply Exterior *Medium Lustre*
- Don't wipe
- Let cure 24 hours

step 6:

- Sand (600 grit)
- Vacuum & tack surface

step 7:

- Apply Exterior *Medium Lustre*
- Don't wipe
- Let cure 24 hours

Exterior Windows & Doors

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration in the initial coat.

Applicator Options

Brush: Natural white china bristle brush (thin coats only)

Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Medium - High Sheen Instructions

step 1:

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 12-24 hours

step 2:

- Sand (400 grit)
- Vacuum & tack surface
(use Mineral Spirits on a rag to clean surface)

step 3:

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 24 hours

step 4:

- Sand (600 grit)
- Vacuum & tack surface

step 5:

- Apply Exterior *Medium Lustre*
- Don't wipe
- Let cure 24 hours

step 6:

- Sand (600 grit)
- Vacuum & tack surface

step 7:

- Apply Exterior *Medium Lustre*
- Don't wipe
- Let cure 24 hours

Repeat steps 6-7 for higher sheen.

Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)