

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Exterior Polymerized Tung Oil Sealer & Medium Lustre Marine Spar Varnish

We recommend Benjamin Moore® and Cabot® exterior oil-based semi-transparent pigmented stains for the best color retention. Once stained, top coating with our exterior line completes your project. Our Old World Concentrated® stains can be used for tinting maintenance coats.

### Stain Instructions

#### step 1:

- Apply recommended exterior stain

*Follow manufacturer's application & curing guidelines.*

### Top Coat Options & Instructions

#### Low Lustre Instructions

##### *Exterior SEALER ONLY*

#### step 2 :

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 24 hours

#### step 3:

- Sand (600 grit)
- Vacuum & tack surface

#### step 4:

- Apply Exterior *Sealer*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### Medium Lustre Instructions

##### *Exterior Medium Luster ONLY*

#### step 2:

- Apply Exterior *Medium Lustre*
- Don't wipe
- Let cure 24 hours

#### step 3:

- Sand (600 grit)
- Vacuum & tack surface

#### step 4:

- Apply Exterior *Medium Lustre*
- Don't wipe
- Let cure 24 hours

#### step 5:

- Sand (600 grit)
- Vacuum & tack surface

#### step 6:

- Apply Exterior *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

#### High Sheen Instructions

##### *Marine Spar Varnish ONLY*

#### step 2:

- Apply *Marine Spar Varnish*
- Don't wipe
- Let cure 24 hours

#### step 3:

- Sand (600 grit)
- Vacuum & tack surface

#### step 4:

- Apply *Marine Spar Varnish*
- Don't wipe
- Let cure 24 hours

#### step 5:

- Sand (600 grit)
- Vacuum & tack surface

#### step 6:

- Apply *Marine Spar Varnish*
- Don't wipe
- Let cure 24 hours

## Exterior Staining

### Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration in the initial coat.

### Applicator Options

**Rag:** Scott® blue paper shop towels

**Brush:** Natural white china bristle brush (thin coats only)

### Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

***Gentle use after 24 hours. Resin fully cures through 7-14 days & full tung oil cure through after 30 days (+/- based on local humidity/elevation/temperature)***