

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Exterior Polymerized Tung Oil Sealer or Medium Lustre

The combination of UV guards, fungicide and Polymerized Tung Oil make this a superior exterior coating for outdoor structures. The elasticity of the Polymerized Tung Oil allows this finish to withstand harsh seasonal cycles. This finish requires timely maintenance to protect the wood.

For easier maintenance choose the Exterior Polymerized Tung Oil Sealer.

### Low Sheen Instructions

#### *Exterior SEALER ONLY*

##### **step 1:**

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 12-24 hours

##### **step 2:**

- Sand (400 grit)
- Vacuum & tack surface

(use Mineral Spirits on a rag to clean surface)

##### **step 3:**

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 24 hours

##### **step 4:**

- Sand (600 grit)
- Vacuum & tack surface

##### **step 5:**

- Apply Exterior *Sealer*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

## Exterior Playsets & Tree Houses

### Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 120 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration on the initial coat.

### Applicator Options

**Brush:** Natural white china bristle brush (thin coats only)

### Coat Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

### Medium Sheen Instructions

#### **step 1:**

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 12-24 hours

#### **step 2:**

- Sand (400 grit)
- Vacuum & tack surface

(use Mineral Spirits on a rag to clean surface)

#### **step 3:**

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 24 hours

#### **step 4:**

- Sand (600 grit)
- Vacuum & tack surface

#### **step 5:**

- Apply Exterior *Medium Lustre*
- Don't wipe
- Let cure 24 hours

#### **step 6:**

- Sand (600 grit)
- Vacuum & tack surface

#### **step 7:**

- Apply Exterior *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

**Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)**