

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Kitchen & Bath Cabinets

### Murdoch's Table Top Satin or Gloss

There are some applications that demand a full film topcoat for maximum durability such as commercial bathroom and kitchen cabinets. Murdoch's Table Top Gloss or Satin with a brush-on application is the best approach for high use areas such as these.

After prepping the wood with Murdoch's Hard Sealer to enhance grain definition, Table Top topcoats are applied to achieve the desired sheen and protection.

#### Satin Sheen Instructions

##### step 1:

- Apply Murdoch's *Hard Sealer*
- Don't Wipe
- Let cure 24 hours

##### step 2:

- Sand 400 grit
- Vacuum & tack surface

(use Mineral Sprits on a rag to clean surface)

##### step 3:

- Apply Murdoch's *Hard Sealer*
- Wait 20-25 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### step 4:

- Sand if rough (600 grit)
- Vacuum & tack surface

##### step 5:

- Apply Murdoch's *Table Top Satin*
- Let cure 24 hours

##### step 6:

- Lightly sand with (600 grit)
- Vacuum & tack surface

##### step 7:

- Apply Murdoch's *Table Top Satin*
- Let cure 24 hours

#### Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration.

#### Applicator Options

**Brush:** Natural white china bristle brush (thin coats only)

**Spray:** HVLP compatible (no dilution necessary)

#### Cure Test

Lightly sand several inconspicuous areas. A fine, white powder indicates that you can safely apply another coat.

#### Gloss Sheen Instructions

##### step 1:

- Apply Murdoch's *Hard Sealer*
- Don't Wipe
- Let cure 24 hours

##### step 2:

- Sand 400 grit
- Vacuum & tack surface

(use Mineral Sprits on a rag to clean surface)

##### step 3:

- Apply Murdoch's *Hard Sealer*
- Wait 20-25 min.
- Wipe unabsorbed finish
- Let cure 24 hours

##### step 4:

- Sand if rough (600 grit)
- Vacuum & tack surface

##### step 5:

- Apply Murdoch's *Table Top Gloss*
- Let cure 24 hours

##### step 6:

- Lightly sand with (600 grit)
- Vacuum & tack surface

##### step 7:

- Apply Murdoch's *Table Top Gloss*
- Let cure 24 hours

entle use after 24 hours. esin fully cures through 7- 4 days & full tung oil cure through after 30 days  
(+/- based on local humidity/elevation/temperature)