

Sutherland Welles Ltd.®

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.



Exterior Polymerized Tung Oil Sealer or Medium Lustre

The combination of UV guards, fungicide and Polymerized Tung Oil make this a superior exterior coating for outdoor furniture. The elasticity of the Polymerized Tung Oil allows this finish to withstand harsh seasonal cycles. This finish requires timely maintenance to protect the wood. For easier maintenance choose the Exterior Polymerized Tung Oil Sealer.

Low Sheen Instructions

SEALER ONLY

step 1:

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 12-24 hours

step 2:

- Sand (400 grit)
- Vacuum & tack surface

(use Mineral Spirits on a rag to clean surface)

step 3:

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 24 hours

step 4:

- Sand (600 grit)
- Vacuum & tack surface

step 5:

- Apply Exterior *Sealer*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Exterior Furniture

Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration on the initial coat.

Applicator Options

Brush: Natural white china bristle brush (thin coats only)

Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

Medium Sheen Instructions

step 1:

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 12-24 hours

step 2:

- Sand 400 grit
- Vacuum & tack surface

(use Mineral Spirits on a rag to clean surface)

step 3:

- Apply Exterior *Sealer*
- Don't wipe
- Let cure 24 hours

step 4:

- Sand (600 grit)
- Vacuum & tack surface

step 5:

- Apply Exterior *Medium Lustre*
- Don't wipe
- Let cure 24 hours

step 6:

- Sand (600 grit)
- Vacuum & tack surface

step 7:

- Apply Exterior *Medium Lustre*
- Wait 10-15 min.
- Wipe unabsorbed finish
- Let cure 24 hours

Gentle use after 24 hours. Light use after 7 days. FULL cure through after 30 days (+/- based on local humidity/elevation/temperature)