



Sutherland Welles Ltd.[®]

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.

Porous Stone



Botanical Polymerized Tung Oil

Our Botanical Polymerized Tung Oil can be used to coat porous stone surfaces such as soapstone, terra cotta, & brick. We recommend working with Botanical Sealer or Low Lustre as the higher sheens will not penetrate as well into the stone. Our Botanical Polymerized Tung Oil line has a strong citrus scent while working & is Greenguard Certified.

~Best option for folks with petroleum sensitivities.~

Before You Get Started

Applicator Options

- **Brush:** Natural white china bristle brush
- **Spray*:** HVLP compatible (no dilution necessary)

*will require back brushing off the excess while working

- **Pad:** Water Based Applicator Pad

Other Tools For Project

Lint free cloth or Scott® blue paper shop towels

Helpful Tools: Fan

Optimal Finishing Conditions

- Weather conditions 55-75°F
- Humidity: 65% or less

Working outside optimal conditions can lengthen curing time between coats and overall. Air flow helps finish the cure. **Tacky surfaces are NOT cured.**

Finishing Concrete?

We recommend that the concrete is fully cured before coating with the Botanical Polymerized Tung Oil. Concrete can be tricky, so we also recommend working in a narrower temperature range (68-75°F) for the cure to work well and timely. Most people use the LOW Lustre as the concrete doesn't absorb much and the oil builds quickly for higher sheen.

Application Instructions

Stone Preparation: All stone surfaces should be free of lint, dirt, grease, wax, & oil. Clean the stone surface with 1 cup ammonia and 1 gallon water. Dry thoroughly.

Strategy: Keep coats *THIN*.

Grout Release Instructions

Use our Botanical Polymerized Tung Oil Sealer for 1-2 coats prior to grouting as a grout release.

Step 1:

- Apply *Botanical Polymerized Tung Oil Sealer*.
- Let cure 24 hours minimum.

Step 2:

- Apply *Botanical Polymerized Tung Oil Sealer*.
- Let cure 24 hours minimum.

Step 3:

- Grout stone

Follow grout manufacture's instructions for cleaning and curing time. Then continue on to preferred top coat application to seal the grout and stone.

Top Coat Application

LOW Sheen: Use SEALER

Step 1:

- Apply *Botanical Sealer*.
- *DON'T wipe off excess.*
- Let cure 24 hours min.

Step 2:

- Apply *Botanical Sealer*.
- Wait 10-15 minutes. Wipe off excess finish gently.
- Let cure 24 hours min.

Step 3:

- Apply *Botanical Sealer*.
- Wait 10-15 minutes. Wipe off excess finish gently.
- Let cure 24 hour min.

MEDIUM Sheen: Use LOW

Step 1:

- Apply *Botanical Low Lustre*.
- *DON'T wipe off excess.*
- Let cure 24 hours min.

Step 2:

- Apply *Botanical Low Lustre*.
- Wait 10-15 minutes. Wipe off excess finish gently.
- Let cure 24 hours min.

Step 3:

- Apply *Botanical Low Lustre*.
- Wait 10-15 minutes. Wipe off excess finish gently.
- Let cure 24 hour min.

Gentle touch after 24 hours. Light use after 72 hours. Do not cover from airflow for two weeks minimum.
Full Polymerized Tung Oil cure through after 30 days (+/- based on local humidity/elevation/temperature)

Sutherland Welles Ltd.[®]

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.

Frequently Asked Questions

General Application & Troubleshooting with Polymerized Tung Oil

What proportion of Mineral Spirits (or Di-Citrusol™) do I mix in to make a Sealer?

Low Lustre: 10% (Low Lustre is VERY close to Sealer), Medium Lustre: 20%, High Lustre: 50%

Why is the time between application and wiping so short compared to your other finishes?

The Botanical Polymerized Tung Oil uses our Di-Citrusol™ Citrus Solvent, which has a much faster drying time than the odorless mineral spirits we use in our other finishes. However this window of time will slow down the older the product is, so if you're using a can that's a few years old you may need to wait 30+ minutes before wiping off excess.

The citrus scent is VERY strong and lingering. How can I minimize this?

We recommend either working with open windows or with good airflow from a fan. Also be mindful of working near heavy upholstery and fabrics, which can absorb the citrus scent of the Di-Citrusol™.

Why are there bubbles in the finish? How do I remove bubbles that dried in the cured finish?

Too much finish is being applied. Use less finish on your applicator and move the wet finish to make a very thin coat. If dried, lightly sand them away with fine sand paper (600 grit should work). If that doesn't work, switch to the next coarser grit of sandpaper using even pressure across the entire surface. Wipe the dust off with a mineral spirits dampened cloth to see if they are gone. Bubbles must be removed before applying more finish.

Why does my finish have tiny spots after the first few coats are cured?

This usually only happens when using a wiping technique with the first couple of coats. It's known as *speckling* or *bleed back*, which is when the oil seeps back out of the wood and cures causing small spots or dots. The friction of wiping speeds up the evaporation of the solvent in the finishes and makes the Polymerized Tung Oil very thin and it migrates to the surface as the solvent gases off. This can be avoided by NOT wiping the excess off your first coat. Apply a thin layer and let it soak into the wood and cure.

How do I get rid of tiny speckles of glossy oil cured on the surface?

See above for how to keep that from happening. It's important to deal with them as soon as you notice them. They aren't going to disappear with adding another coat. Sand the surface lightly with 400 grit sand paper. Wipe the surface down with mineral spirits on a cloth. Let dry and observe the surface. If it's a large surface area, but not all areas have the spots, you should still sand the entire surface. You can't spot sand and have the end result be uniform.

Why do I have uneven sheen with streaks of dull and shiny areas?

There are two possibilities for what could be happening. When there isn't even surface build on the wood itself, the wood has deeply absorbed the finish. Keep "feeding" the wood more polymerized tung oil by building coats up until it all evens out on the surface coats. This is common with "thirsty" woods like Walnut.

If you have an even surface build and this is happening WITHIN the finish coats, then you have streaking and flashing. This happens when a prior coat of finish didn't dry properly, most likely due to humidity shifts, before another coat was applied. Moisture is trapped under the surface of the finish creating the streaks. This will need to be sanded back down to that layer and allowed to dry and re-coated.

Why am I seeing scratch marks in the wood?

You did not effectively sand out these marks before application. Oil finishes will absolutely highlight improper sanding marks. You will have to sand them out with a courser sandpaper and rebuild from there.

What can I use to fill in voids in the wood?

Two-part epoxy. You can take it a step further and mix sanding dust with the epoxy before filling. You can also purchase tinted epoxy or dyes to add to epoxy to match or highlight the voids after at least 1 coat of finish is applied.

What if I want to stain this project?

Please refer to our Staining Instructions for more information and techniques of staining with the Old World Concentrated Stains and polymerized tung oil. If using another brand, follow their curing instructions before applying polymerized tung oil over. Only mix with aniline dyes or OIL based stains/paint if tinting.

Sutherland Welles Ltd.[®]

Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.

Frequently Asked Questions

Care Instructions for a Polymerized Tung Oil Finish

How Do I Care for a Polymerized Tung Oil Finish?

- **CLEAN:** Use *Sutherland Welles Ltd.[®] Wood Cleaner* OR 1 cup vinegar or ammonia to 1 gallon warm water* with a soft, clean cloth. Do not use any cleaner with a SOAP base (Murphy's Oil Soap/Bona etc.) under any circumstances, as they will leave a film that will gum up the surface of the oil. Do not use a steam cleaner.
*Ratio is 1 part vinegar or ammonia to 16 parts water to scale up or down as needed.
- **REFRESH:** Apply *Sutherland Welles Tung Oil Polish* and buff with a clean dry cloth. This will help with the longevity of the finish, delaying the need to re-coat.
- **RE-COAT:** Scuff lightly with fine steel wool, sandpaper or pad. Vacuum & Tack. Re-apply finish as needed.

Can I spot repair a polymerized tung oil finish?

Yes, you can if there is a scratch or blemish on the finish. Sometimes wiping our polymerized tung oil over a scratch will make them disappear and blend in. Blemishes or marks in the surface layer of finish will need to be removed by lightly sanding with fine sandpaper first. Sometimes the entire board will need to be refinished to have it blend in or the entire surface of a counter top or table.

Can I use a wax over your products?

If you choose to, we recommend using *Teddy's Polymerized Tung Oil Paste* a week after the last coat is applied. Keep in mind that wax has a tendency to "halo" or leave rings on a dining room table under hot drinks/food. It will also need to be removed before any re-coating can occur. We suggest not using wax on dining tables, counters, or coffee tables if wet drinks will be placed there. *Sutherland Welles Ltd.[®]* also has a *Tung Oil Polish* that is a great alternative to paste wax. It can be used as extra protection and as maintenance product.

Storing Polymerized Tung Oil

I have an unopened can of finish. How long is it good for?

With the exception of our Exterior line of products, any unopened can of our finish has no shelf life. The citrus solvent in the Botanical line may shift in color over time, but it is still workable as a finish.

What's the BEST way to store an opened can of finish?

These are the two most reliable way to store residual finish. Both options are available for purchase on our website:

- **StopLossBags[®].** The bags are made with a plastic that can withstand a variety of solvents and not breakdown so the product is preserved in an oxygen free environment and remains shelf stable indefinitely.
- **Bloxygen** displaces oxygen with ultra-pure Argon, a nontoxic, inert gas naturally found in the air. It prevents thickening, gelling, skinning, and clogged spray guns caused by oxygen exposure.

Other methods:

- Clean the inner rim of the can well so the plug seats uniformly and firmly in place and store it inverted.
- You can also pour it into a smaller container (metal or glass) leaving little air space- make sure to label it properly. Perfect way to reuse old sauce or jam jars!
- Marbles or clean rocks can also be dropped in to take up the airspace.

What can I do if my finish gels up in the can after I have opened it?

This only happens in a partially full can that has been used. If the finish is thick and gel-like, the finish has oxidized in the can. You can attempt to thin it down by adding mineral spirits or our *Di-Citrusol[™]* and stirring it gently to see if you can coax it back into solution. You may need to pass it through a fine paint strainer to remove any small globs.

For more tips & tricks, visit our Youtube page for video tutorials:

youtube.com/@sutherlandwellesltd