

# Sutherland Welles Ltd.®

*Sustainable, natural & earth-friendly Polymerized Tung Oil wood finishes.*



## Interior Ceilings, Beams & Mantles

### Wood Preparation

All wood surfaces should be free of lint, dirt, grease, wax, oil and old paint. If you are refinishing old wood, please make sure to remove any loose old finish. **Sand the wood using 220 grit paper.** Avoid using higher grits as they close down the wood pores interfering with maximum penetration.

### Applicator Options

**Rag:** Scott® blue paper shop towels

**Brush:** Natural white china bristle brush (thin coats only)

**Spray:** HVLP Compatible (no dilution necessary)

### Cure Test

Push finger tips against the grain of the wood. If they glide easily over the surface, you are ready to apply your next coat.

## Interior/Original Formula Polymerized Tung Oil

### Sealer or Low Lustre

For finishing Interior Ceilings, Beams & Mantles we recommend our Interior/Original Formula Tung Oil. This line is all Polymerized Tung Oil with no resin fortification. The Interior/Original Formula Tung Oil is made with a petroleum solvent. The solvent becomes airborne and dissipates leaving the exact same oil in and on the wood.

### Ceiling Instructions

#### Low Sheen

##### Sealer ONLY

##### step 1:

- Apply *Sealer*
- Don't Wipe
- Let cure 24 hours

##### step 2:

- Sand 400 grit
- Vacuum & tack surface

(use Mineral Sprits on a rag to clean surface)

##### step 3:

- Apply *Sealer*
- Wait 25-30 min.
- Wipe unabsorbed finish
- Let cure 24 hours

**Repeat steps 2-3 for higher sheen.**

### Beam & Mantle

#### DENSE Wood Instructions

#### Low-Medium Sheen

##### Sealer ONLY

##### step 1:

- Apply *Sealer*
- Don't Wipe
- Let cure 24 hours

##### step 2:

- Apply *Sealer*
- Wait 25-30 min.
- Wipe unabsorbed finish
- Let cure 24 hours

**Repeat step 2 for higher sheen.**

### Beam & Mantle

#### POROUS Wood Instructions

#### Low-Medium Sheen

##### Low Lustre ONLY

##### step 1:

- Apply *Low Lustre*
- Don't Wipe
- Let cure 24 hours

##### step 2:

- Apply *Low Lustre*
- Don't Wipe
- Let cure 24 hours

**Repeat step 2 for higher sheen.**